

# TOSHIBA

## STAYING CONNECTED MATTERS.

#DetailsMatter



SMART ASSISTANT



RELIABLE PARTNER



TIMELY SUPPORT

### REMOTE CONTROL



The operation mode of the refrigerator can be controlled remotely on the APP.

- Adjust Temperature
- Super Cooling
- Super FRZ.
- Auto mode

### FOOD MANAGEMENT



TOSHIBA's food management feature allows you to monitor the freshness of your food at all times. Organize your food regularly to prevent waste.

### ENERGY CONSUMPTION



Automatic statistics of weekly, monthly, and annual power consumption so that the user is always aware of the refrigerator's power consumption and provides energy-saving tips according to the refrigerator's habits.

### ECOMASTER



Turn on ECOMASTER at the time you set to automatically adjust your refrigerator's temperature and defrost time, which can help you save energy and electric charge.

### OPEN-DOOR ALARM



Send reminder when the REF is not closed properly.

### FAMILY CARE



Check the REF's opening record by family members. Send a reminder if the REF has not been opened during the setting time.

### OTA UPGRADE



Delivering sustainable and scalable IoT services.

### SELF DIAGNOSTICS



The refrigerator can actively perform self-tests for abnormalities, analyse faults and fix them with a single click, helping users to solve problems faster and more effectively.

### AFTER-SALES



The user can call the after-sales by one click, and check the common FAQ, user manual on the APP.

- After-sales
- FAQ information
- E-manual

\* Actual functions are subject to the version after activating the appliances




TSmartLife



# QUICK START GUIDE

## 1 DOWNLOAD THE TSmartLife APP

Scan QR code or find us on your app store



## 2 REGISTER AND LOG IN

Log in for existing users or sign up for new users




## 3 CONNECT YOUR DEVICES TO TSmartLife

**A.** Connect to wireless network and enable Bluetooth

**B.** Open the TSmartLife app. Power on selected device

**C.** Add your device using one of the following methods:



## QUICK TIPS

- Make sure your devices are powered on.
- Keep your mobile phone close to your device during connection.
- Connect your mobile phone to the wireless network at home.
- Enable the 2.4GHz frequency on your wireless network router. Contact the manufacturer if unsure whether the router supports 2.4GHz.
- The device is unable to connect to wireless network that requires authentication and also appears in public areas such as hotels and restaurants.
- It is recommended to use a wireless network name that only contains letters and numbers. If your wireless network name contains special characters, modify it in the router. Disable WLAN+ (Android) or WLAN Assistant (iOS) when connecting your devices to the network.
- To reconnect a device to the wireless network, click "+" on the app home screen and add the device again by the category and model according to the app prompts.

[www.toshiba-lifestyle.com](http://www.toshiba-lifestyle.com)

# TOSHIBA