

TOSHIBA

STAYING CONNECTED MATTERS.

#DetailsMatter



SMART ASSISTANT

RELIABLE PARTNER

TIMELY SUPPORT

REMOTE CONTROL

- Adjust Temperature
- Super Cooling
- Super Freezing
- Vacation Mode

FOOD MANAGEMENT

- You can always monitor the freshness of food to prevent waste.

FRESH DRINK

- Put drinks into the freezer zone, and the app will send reminder when the drinks are chilled.

ENERGY CONSUMPTION

- Automatic statistics of weekly, monthly, annual electricity consumption and give energy saving tips.

ENERGY MODE

- Automatically set the temperature to 8°C/-16°C, which can reduce energy consumption by about 15%.
- Allows to set off-peak period.

OPEN-DOOR ALARM

- Send a reminder when the fridge is not closed properly.

HOME AWAY MODE

- Send a reminder if the fridge is opened accidentally.

FAMILY CARE

- Check the fridge's opening record by family members.
- Send a reminder if the fridge has not been opened during the setting time.

OTA UPGRADE

- Delivering sustainable and scalable IoT services.

AI DIAGNOSIS

- The refrigerator can actively perform self-tests and analyse faults, helping users to solve problems faster and more effectively.

AFTER-SALES

- Click to call after-sales
- FAQ information


* Actual functions are subject to the version after activating the appliances



QUICK START GUIDE


1 DOWNLOAD THE TSmartLife APP

Scan QR code or find us on your app store



2 REGISTER AND LOG IN

Log in for existing users or sign up for new users




3 CONNECT YOUR DEVICES TO TSmartLife

A. Connect to wireless network and enable Bluetooth

B. Open the TSmartLife app. Power on selected device

C. Add your device using one of the following methods:



QUICK TIPS

- Make sure your devices are powered on.
- Keep your mobile phone close to your device during connection.
- Connect your mobile phone to the wireless network at home.
- Enable the 2.4GHz frequency on your wireless network router. Contact the manufacturer if unsure whether the router supports 2.4GHz.
- The device is unable to connect to wireless network that requires authentication and also appears in public areas such as hotels and restaurants.
- It is recommended to use a wireless network name that only contains letters and numbers. If your wireless network name contains special characters, modify it in the router. Disable WLAN+ (Android) or WLAN Assistant (iOS) when connecting your devices to the network.
- To reconnect a device to the wireless network, click "+" on the app home screen and add the device again by the category and model according to the app prompts.

www.toshiba-lifestyle.com

TOSHIBA