TOSHIBA

STAYING CONNECTED MATTERS.

#DetailsMatter









REMOTE CONTROL




- Adjust Temperature
- Super Cooling
- Super Cooling
 Super Freezing
- Auto Mode

AFTER-SALES



- · Contact Number
- Common FAQ

HOME AWAY MODE



• Set reminder if the fridge is opened accidentally.

FAMILY CARE



- Check the fridge's opened record by family members.
- Send reminder if the fridge has not been opened during setting time.

OPEN-DOOR ALARM



Set reminder when the fridge is not closed properly.


 $[\]ensuremath{^*}$ Actual functions are subject to the version after activating the appliances



QUICK START GUIDE

1 DOWNLOAD THE TSmartLife APP

Scan QR code or find us on your app store




2 REGISTER AND LOG IN

Log in for existing users or sign up for new users



3 CONNECT YOUR DEVICES TO TSmartLife

- A. Connect to wireless network and enable Bluetooth
- **B.** Open the TSmartLife app. Power on selected device
- C. Add your device using one of the following methods:



QUICK TIPS

- Make sure your devices are powered on.
- Keep your mobile phone close to your device during connection.
- Connect your mobile phone to the wireless network at home.
- Enable the 2.4GHz frequency on your wireless network router. Contact the manufacturer if unsure whether the router supports 2.4GHz.
- The device is unable to connect to wireless network that requires authentication and also appears in public areas such as hotels and restaurants.
- It is recommended to use a wireless network name that only contains letters and numbers. If your wireless network name contains special characters, modify it in the router. Disable WLAN+ (Android) or WLAN Assistant (iOS) when connecting your devices to the network.
- To reconnect a device to the wireless network, click"+" on the app home screen and add the device again by the category and model according to the
 app prompts.

www.toshiba-lifestyle.com

